GUARDIAN BUILDING PRODUCTS (QLD.) PTY. LTD.

Product Data Sheet



READIPANEL TOUCH UP PROCEDURE

In the event that the ReadiPanel supplied may require touching up owing to minor damage related to site handling, transport handling or site cutting of sheets, each consignment is supplied with a small quantity of matching colour touch up paint.

It is important to recognize that the system provided is a fully coated and sealed panel with generally the exposed face and all edges being painted to the selected colour, and the rear of the panel sealed with an impervious clear sealer. It therefore becomes imperative that this sealed environment be maintained following any site cutting of sheets.

The following procedures should be adopted when treating either minor panel surface damage or site cutting of sheets.

Touch Up Paint Procedure:

The touch up paint provided is supplied in two parts being (1) Paint (selected colour) and (2) Hardener.

When preparing, you should mix three (3) parts paint to one (1) part hardener.

Failure to mix in the above stated proportions (or close to them) will result in paint drying and hardening concerns.

Mechanical Damage Repair.

Minor damage to the panel can generally be repaired with a small fine hair brush and touch-up paint supplied with the original consignment of pre-finished panels.

Any significant damaged caused to the panels will require consultation with Guardian Building Products (Qld) Pty Ltd, to assess the most appropriate option of repair being either an on site paint and panel repair or panel replacement.

Finishing of edges cut on site.

Having established the line where the panel is to be cut, place 50mm wide blue painter's masking tape over the line with 10mm of the tape on the waste side of the cut.

The cut should be made with a diamond blade saw, ensuring that the base plate does not scratch the painted surface of the panel. With the masking tape still in place, slightly round the panel edge to a 1mm radius with sand paper.

Spray apply one even coat V188 WRP on the cut edge. Wipe V188 overspray off the face of the panel and leave to dry approx. 10-15 minutes until CFC returns to original appearance. Mix A20/A10 A&B and apply carefully until covered. Application methods for paint can be brush, roller or squeegee. (Touchup accessories available from Guardian – see overleaf)

Readipanel touch up accessories available from Guardian Building Products (Qld) Pty Ltd

V188 WRP sealer: 500ml spray bottle.

1000ml spray bottle.

Blue UV resistant Painters tape: 36mm x 50m Roll.

48mm x 50m Roll.